


Noby 220iR2

Fire Alarm Control Panel



Installation Manual

Please read these instructions carefully and retain them in a safe place for future reference.

IX-02-151

Contents	Page
Noby-220iR2 Overview	3
Installation and Commissioning	6
Location and mounting the Noby-220iR2	6
Connecting the 230VAC supply	6
First power up	7
Connecting the detectors	7
Connecting the external sounders	7
One-man test	8
Automatic Re-sound Option	8
Input / Output Terminals	9
External Fault Input	9
Fault Output	9
Interlink Data Bus	10
Interlink Programming	10
LED Strobe / Lamp Output	13
Relay Output	13
Engineer Disablement Options	14
Panel Behaviour	15
Audible alarms, faults & warnings	15
Panel Reset	15
LED Lamp and 230VAC Mains Loss	15
Maintenance	15
Troubleshooting	16
Warnings & Cautions	17
Specification	18
User Operation	21
LED Display Indications	22

Noby-220iR2 Overview


The Noby-220iR2 Fire Control Panel is an enhanced version of the standalone Noby-220, fitted with an interlink data bus for connecting up to 8 control panels. Fire Alarms and Fault Warnings are signalled across the interlink bus connection to alert neighbouring properties.

Local alarms are audibly signalled with a continuous sounder tone, whilst remotely triggered alarms are differentiated with pulsing sounders. The origin of a fire alarm is identified on the latching LED display at all remotely connected panels. A 60s delay on transmitted fire alarms provides a time window in which to cancel a nuisance false alarm.

Silencing the panel-in-alarm will automatically silence all connected panels, provided that no new alarm has been triggered from another panel. Each property owner can silence their own local sounders manually at *their* panel. All panels will re-sound upon receipt of a new fire alarm. Fire alarm LED indication is latched until a Panel Reset is performed at each individual property.

Fault LED indications remain latched at the local property until the panel is reset. Fault conditions originating from remote properties are displayed in real-time at the local panel, and the LED indications are automatically cleared when the remote panel is reset. Audible fault tones are only provided at the local property.

The Noby-220iR2 control panel is fully monitored according to EN54-2 and EN54-4 standards, and the interlink data connection is securely monitored for physical disconnection and/or data errors.






Figure 1: Detector and Sounder Circuits




Figure 2: Internal Layout

Installation and Commissioning

This equipment is to be installed, serviced and maintained by a suitably qualified technical person with the requisite knowledge of electrical and fire safety installations.

Location and Mounting

It is best to locate the Noby-220iR2 in a public space, e.g. a hallway or landing area, where the LED Strobe/Lamp is visible and the internal alarm sounder can be clearly heard. Another consideration is to position the panel to make most effective use of the LED Strobe/Lamp, which switches on automatically in the event of mains power loss.

The Noby-220iR2 is intended for indoor use only, and must be sited in a dry environment. Do not site the Noby-220iR2 outside, or in any location where it may become exposed to damp or freezing conditions.

All components are selected to operate within their specification when the environmental conditions outside the enclosure comply with class 3k5 of EN60721-3-3:1995; temperature range -5°C to +40°C; 95%RH. The enclosure is rated at IP30, which offers protection against tools and wires greater than 2.5mm width, but no protection against liquids.

Mount the Noby-220iR2 securely onto a flat solid surface at the three fixing points denoted by 'MH' in Figure-2, using wall fixings appropriate for the material. In some situations it may be desirable to recess the panel into a hollow section wall, in which case the 'Noby-220iR2 Flush Mounting Kit' provides the necessary fixing harness and stainless steel frame.

Connecting the 230VAC supply

Connect the 230VAC to the Noby-220iR2, paying strict attention to local wiring regulations. A readily accessible disconnect device shall be incorporated into the building installation wiring. Feed the cable securely through the rear cable-entry hole CE2, or via a 20mm cable-gland CG4.

Alternatively a 3-core 230VAC flexible cord can be fed through CG5 (top) or CG6 (bottom) using the strain relief bush supplied (suitable for cable diameters 6.2mm to 7.4mm). In this case ensure that the cord is connected to the building installation wiring via a readily accessible disconnect device fitted with a 2A fuse.



Strip back the outer sheath of the cable 25mm and then strip back each inner core 6mm, such that the cable double insulation is preserved inside the enclosure to within 25mm of the screw terminals.



The Noby-220iR2 is Class-1 equipment and shall be earthed. Connect the earth core of the incoming cable to the earth point on the enclosure. Consult a qualified electrician if there are doubts concerning electrical safety.

First power up

It is recommended that the Noby-220iR2 is first powered up with the End Of Line devices still connected to the screw terminal block at the panel, as supplied from the factory. This will help to establish that the panel is functioning OK before connecting any external devices.

- Switch off or disconnect the 230VAC supply.
- Position the battery as shown in Figure-2, with the -ve terminal to the rear of the enclosure.
- Connect the battery terminals, observing strict battery polarity.
- Press the pushbutton marked “Batt Start”.
- The panel powers up indicating a PSU fault, accompanied by a fault tone (2 beeps every 4s).
- The LED Strobe Lamp is automatically activated due to there being no 230VAC at this time.
- Switch on the 230VAC supply to the panel.
- The green Power LED blinks (occults) every 4 secs, indicating that 230VAC has been absent (memory).
- Perform a Panel Reset (*refer to User Operation on page 21*).
- The Noby-220iR2 should now be in standby mode with a steady green Power LED and blue backlight.

Connecting the detectors (*Figure 1*)

- Up to a maximum of 10 detectors can be connected to each zone.
- Up to a maximum of 10 call-points can be connected to each zone.
- Ensure that the detectors are within specification to operate at 10.5 volts.
- Use detector bases fitted with a schottky diode.
- Connect the detectors and call-points in a straight daisy-chain manner, with no spurs or loops.
- The recommended maximum cable length on each circuit is 100m.
- Maintain strict polarity from the panel, and from one detector to the next.
- Remove & re-connect the factory fitted EOLC at the outermost detector base.

Connecting the external sounders (*Figure 1*)

- The total combined sounder circuit current available across both circuits, is 150mA.
e.g. up to 10 sounders can be connected with a current draw of 15mA each.
- The sounders must be compatible with conventional fault monitoring (polarised).
- Ensure that the sounders are within specification to operate at 10.5 volts.
- Connect the sounders in a straight daisy-chain manner, with no spurs or loops.
- The recommended maximum sounder cable length is 100m per loop.
- Maintain strict polarity from the panel, and from one sounder to the next.
- Remove & re-connect the factory fitted EOLR at the outermost sounder.

One-man test

The one-man test is a test facility to aid commissioning and testing of the system, allowing the installer to walk-test the system and trigger each detection device in turn.

- Enter the Engineer Access Code-2         followed by .
- Press either  and/or  to toggle on/off the desired zone/s for testing.
- The selected zone/s are indicated by rotating LED patterns on the corresponding pushbutton/s.
- You now have 90s to trigger the first device, and 90s thereafter to trigger the next device.
- Each triggered device will pulse the sounders and flash the red zone LEDs until the test alarm condition is clear. The panel automatically resets the detectors. Note that the relay output remains unaffected by the one-man test mode.
- Press  to exit the one-man test mode.

Note: The panel automatically kicks back to normal standby User Mode after 90s of no activity, or if there is a real fire condition detected on a zone not being tested.

Automatic Re-sound – Programmable Option

It is a requirement of EN54-4 that it must be possible to configure the fire panel to automatically re-sound following an alarm in *another* zone. This is the default factory setting for the Noby-220iR2. The panel can be reconfigured to automatically re-sound following an alarm only in the *same* zone by clearing the option switch. From normal standby User Mode enter the following key sequence:

<i>Engineer Access Code-1</i>	<i>Select</i>	<i>Toggle</i>	<i>Auto Re-sound Option</i>
       			LEDs Off= No Auto Re-sound LEDs On= Auto Re-sound*

* Factory default setting

- The green Power LED flashes rapidly upon successfully entering the Engineer Access Code-1.
- The LEDs surrounding button  indicate the current option status.
- Toggle button  to set/unset the desired option.
- Press  to accept **OR** press  to quit without updating the option.

Input / Output Terminals




Figure 3:
Input / Output
Terminal Strip

External Fault Input (Terminal 1)

The Fault Input terminal permits a fault signal from external equipment to be indicated on the Noby-220tR2 control panel. The LED indication is non-latching i.e. the LED follows the Ext. Fault Input status. The polarity of the input is programmable. The factory setting is for a +12V signal to be applied to the terminal to bring up a fault indication. Note that connecting external equipment also requires a ground reference connection i.e. 0V from the external equipment must be connected to 0V on the Noby-220tR2 (Terminal 4). From normal standby User Mode enter the following key sequence:

Engineer Access Code-1	Select	Toggle	Fault Input Polarity Option
1 2 1 2 2	1	1	LEDs Off= +12V applied* LEDs On= +12V removed

* Factory default setting

- The green Power LED flashes rapidly upon successfully entering the Engineer Access Code-1.
- The LEDs surrounding button 1 indicate the current option status.
- Toggle button 1 to set/unset the desired option.
- Press to accept **OR** press to quit without updating the option.

Fault Output (Terminal 2)

A 12V/20ma open-collector output signal. Normally high (12V), it falls to 0V upon detection of any fault originating at the **local panel only** i.e. does **not** include the Ext. Fault Input, interlink bus faults, or any fault originating at a remote panel. Note that connecting external equipment also requires a ground reference connection i.e. 0V on the Noby-220tR2 (Terminal 4) must be connected to 0V on the external equipment.

interlink data bus (Terminal 3)

The interlink data bus has been laboratory tested with up to 1km of standard low-grade alarm cable (92mohm/m 160pF/m), connected in different configurations i.e. linear, star, clustered etc.. These tests were conducted in a simulated electrically noisy environment, but we appreciate that real world installations can be more harsh and varied. We therefore specify that the **maximum installed interlink cable length is 250m**, which provides a four fold safety margin. Installations exceeding 250m are not guaranteed by Noby UK and are undertaken at the installer's risk.

The overriding limiting factor is that the *total* installed cable capacitance must not exceed 100nF i.e. the pF/m multiplied by the *total* length of cable used. Also, the total circuit resistance must not exceed 100ohms (or 50ohms per leg). Wherever possible avoid running the cable in close proximity to transmitter devices, or in conduits containing potentially noisy electrical cables. Screened cable *may* provide some immunity in excessively noisy environments (e.g. near RF transmitters etc.) - with the screen connected to a good clean earth at one point only on the system.

The data connection is low speed and there is little advantage to be gained in using more expensive high speed data cable, although national regulations might stipulate the use of flame retardant cable. The protocol is fail safe, meaning that in the event of a cable burn-out all remote panels will continue performing according to the last signal received, and at the very least they will continue to function as standalone fire control panels.

If this is your first Noby-220iR2 installation then it is highly recommended to familiarise yourself with the system and program the addresses on the work bench, rather than on site with the panels distributed across 8 properties.

interlink Programming

As supplied from the factory the interlink is disabled and the Noby-220iR2 defaults to offline, acting as a single standalone fire control panel. To enable the interlink connection each Noby-220iR2 panel must be programmed with a UNIQUE address according to the procedure set out below.

The addresses can be programmed with the panels online or offline, whichever is the more convenient. Online 'live' programming guarantees that all addresses are unique since the system seeks free address slots. You may start with just one panel, and then add further panels one by one, each time programming the address at the newly added panel. The system allocates the next available address number, such that the address numbers 1 to 8 are programmed according to the order in which the panels are added.

Offline (manual) programming requires a more methodical approach, and carries a greater risk of duplicating one or more addresses.



The possibility of duplicating addresses exists where panels are either pre-programmed off-site or swapped from another system. The symptoms of a duplicated address are not always immediately obvious, although in most circumstances a Bus Error Fault will be indicated.




Figure 4:
interlink
Programming
LED Display

LED Indications:

A steady green LED indicates that **this** panel is **interlink** enabled.

A steady red LED indicates that **this** panel is **interlink** disabled i.e. no address programmed.

The pulsing red LED indicates the programmed address number 1 to 8 of **this** panel.

The 8 yellow pushbutton LEDs indicate the detection of all connected panels on the **interlink** bus, with **this** panel's LED rapidly flashing.

Procedure:

- Enter the **interlink** Code .
- Allow 5 seconds for scanning - the 8 yellow pushbutton LEDs cycle around.
- Press to seek the next available address - indicated by a rapid flashing pushbutton LED.

- OR -

- Press to clear the address and disable **this** panel's **interlink** functionality.
- Press to accept **OR** press to quit without updating the option.
- Allow 8 seconds for the system to stabilise before proceeding with other panel operations.

Note: The panel automatically kicks back to normal standby User Mode after 60s if left unattended.

Removing a Noby-220iR2 panel from the **interlink** bus

A panel may be effectively switched offline by clearing its address as described in the above procedure.

interLink Remote Alarm 60s Delay - Programmable Option

As supplied from the factory all fire alarms signalled across the interlink data bus are delayed by 60s to help reduce nuisance alarms at connected properties.

<i>Engineer Access Code-1</i>	<i>Select</i>	<i>Toggle</i>	<i>Relay Option</i>
 1 2 1 2 2  	2	2	LEDs Off= i Link Instant Alarm LEDs On= i Link 60s Alarm Delay*

* Factory default setting

- The green Power LED flashes rapidly upon successfully entering the Engineer Access Code.
- The LEDs surrounding button **2** indicate the current option status.
- Toggle button **2** to set/unset the desired option.
- Press  to accept **OR** press  to quit without updating the option.

LED Strobe / Lamp Output (Terminal 5)

An external LED Strobe/Lamp can be connected between Terminal 3 (anode +ve) and Terminal 4 (cathode -ve). This 12V open-collector output mimics the internal LED Strobe/Lamp and is current limited to 20mA with an on-board 220ohm resistor.

Relay Output (Terminal 6,7,8) - Programmable Option

As supplied from the factory the relay operates as a Fire Alarm relay, but it can alternatively be programmed to operate as a Fault Output Relay by keying the following sequence:

Engineer Access Code-1	Select	Toggle	Relay Option
 1 2 1 2 2  	2	1	LEDs Off= Fire Alarm Relay* LEDs On= Fault Relay

* Factory default setting



Note that when programmed as a Fault Output the relay is normally in a de-energised state in order to conserve standby battery power. Total power loss will therefore **not** be signalled to external equipment.

- The green Power LED flashes rapidly upon successfully entering the Engineer Access Code.
- The LEDs surrounding button  indicate the current option status.
- Toggle button  to set/unset the desired option.
- Press  to accept **OR** press  to quit without updating the option.

Engineer Disablement Options

The Noby-220iR2 is supplied as a fully functional fire alarm control panel with comprehensive fault monitoring to meet the requirements of the EN54 standard. The following programmable disablement options are provided as a tool to assist the installer in fault finding, such as compatibility issues with 3rd party detectors and sounders. The installer should be aware that the permanent use of these disablement options may have a bearing on the overall safety and approval status of the system. Any permanent setting of these options is undertaken solely at the risk of the installer.

From normal standby User Mode enter one of the following key sequences:

Engineer Access Code-2	Select	Toggle	Disablement Option
(1) (2) (2) (1) (1)		(1)	Disable all Sounder Circuits <i>(internal 85db sounder also reduced to 65dB)</i>
(1) (2) (2) (1) (1)		(2)	Disable Alarm Relay
(1) (2) (2) (1) (1)	(1)	(1)	Disable Detector S/C Faults (s/c zones => fire condition)
(1) (2) (2) (1) (1)	(1)	(2)	Disable Detector Head Removal & O/C Fault Monitoring.
(1) (2) (2) (1) (1)	(2)	(1)	Disable Battery Fault Monitoring
(1) (2) (2) (1) (1)	(2)	(2)	Disable Sounder Circuit Fault Monitoring

- The green Power LED flashes rapidly upon successfully entering the Engineer Access Code.
- The LEDs surrounding buttons (1) and (2) indicate the current option status.
- LED on = option set; LED off = option cleared (factory default).
- Toggle button (1) or button (2) as required.
- Press to accept **OR** press to quit without updating the option.

Panel Behaviour

Audible alarms, faults & warnings

In the event of a fire alarm the internal piezo sounder emits a loud rapid pulsing tone, and the external sounder circuit is activated, together with the fire alarm relay (if it has not been re-programmed as a fault relay). All circuit and system faults are accompanied by a fault tone i.e. a double beep every 4 seconds. A warning tone is signified by a double beep every 60s and is most likely to occur when there is loss of the 230VAC supply or 230VAC Mains Loss condition lasting longer than 90s.

Panel Reset

A Panel Reset attempts to reset the detector circuits and clear the latched LED indications. All the panel LEDs are lit during the 3 second reset period. Note that a standing fire alarm or fault condition will immediately re-trigger the sounders following a Panel Reset.

LED Lamp and Mains Power Loss

Under normal circumstances the LED Lamp can be switched on for a self-timed period of 10 minutes, or switched on permanently by means of the [Lamp] button. In the event of a 230VAC power-cut the LED Lamp is automatically activated and self-timed for 60 minutes. The Lamp can be manually re-triggered for a further 60 minute period by pressing the [Lamp] pushbutton. Note that in the interest of conserving battery power it is not possible to switch the LED Lamp on permanently during a power-cut. Also, the blue backlight is automatically disabled to conserve battery power.

Maintenance

Once installed the Noby-220*t*R2 should provide many years reliable service. Routine testing and periodic system maintenance should be undertaken by a competent person and in accordance with local statutory regulations. With the exception of fuse replacement there are no user-serviceable parts inside the enclosure. Although the standby battery is monitored for presence and capacity, it is nevertheless recommended as a preventative measure to replace the battery at 4 year intervals.

In the event of a suspected fault with the control panel it is advised to disconnect the external loop wiring and fit EOL resistors/capacitors directly at the control panel screw terminals. In this way it becomes possible to determine whether the control panel itself or some other external factor is causing the fault.

The Noby-220*t*R2 should be cleaned with a damp cloth. Avoid the use of detergents and solvents because these could react with the inks and plastic parts of the fascia. Ensure that water does not enter the enclosure.

Troubleshooting

The green Power LED is not steady

Check that the mains supply is connected and switched on.

The panel will not power-up when connecting the battery

A requirement of EN54-4 is to electronically disconnect the battery when the voltage deep discharges to 10.5v. When connecting a battery it is therefore necessary to manually kick-start the system by momentarily pressing the pushbutton marked "Batt Start". If the panel does not start up then check the battery fuse F3 and/or the condition of the battery.

The Common Fault LED will not clear

Refer to the LED Indications (page 22) to determine the cause of the fault.

Ooops, I accidentally connected the battery the wrong way round

We've all done it at some time or other! Replace fuse F3 (T1.0A) and try again.

A smoke detector generates a fault instead of a fire

Some (older) detectors and call-points are not compatible with modern panels equipped with short circuit fault monitoring. One remedy is to connect a resistor in series with each affected detector head - any value in the region of 400 to 1000 ohms is suitable. Some detector bases allow spare terminals for this purpose. Care must be exercised not to inadvertently insert this resistor in series with the main cable run, as this will lead to other erratic behaviour.

Another work-around is to set the programmable Engineer Disablement Option: Disable Detector S/C Fault Monitoring. In this case all detector short circuits will be interpreted by the panel as a fire condition.

There's a persistent zone fault that can't be cleared

Check all the detector heads are both present and securely located to their bases.

Check base connections, paying particular attention to correct polarity.

Check that the EOLC is fitted across the final detector.

Check that the detector bases are of the schottky diode type.

Programme the Engineer Disablement Option: Disable Detector Head Removal Monitoring. If this clears the fault then the problem is likely to be related to one or more bad detector base/head connections. Note: setting this option also disables o/c monitoring and is therefore not recommended as a permanent fix - the purpose of the option is to help eliminate one possible cause of a fault.

Failing the above suggestions, it's down to the systematic process of elimination ie. relocate the EOLC to the first device and disconnect the remaining detectors, then move onto the second device etc.. Repeat until the fault shows up.

There's a persistent sounder fault that can't be cleared

Check that the sounders are the polarised type and compatible with conventional fire panel fault monitoring.

Check the cable connections at each sounder for correct polarity, and that the EOLR is connected across the final sounder on each circuit.

Warnings & Cautions

	Clean external surfaces with a damp cloth and mild detergent. Do not use abrasives, solvents or polish.
	Noby UK have taken every reasonable effort to ensure that the stainless steel facia is delivered in pristine condition. Please inspect the facia prior to installing the product as Noby UK cannot accept responsibility for any flaws or scratches incurred during installation.
	This equipment is to be installed, serviced and maintained by a suitably qualified technical person with the requisite knowledge of electrical and fire safety installations.
	Take care not to accidentally reverse the battery connections during installation. Fuse F3 offers some protection but there is still a possibility of permanent damage to the electronic circuitry. Such damage is identifiable to Noby UK and is not covered by the warranty.
	The Noby-220iR2 shall be permanently connected to the 230VAC building installation wiring via a readily accessible disconnection device and in accordance with local wiring regulations.
	Part of the internal circuitry operates at 230VAC and presents an electrical shock hazard. Do not attempt to open, dismantle, repair or tamper with this equipment without first disconnecting the mains supply voltage.
	The Noby-220iR2 is Class-1 electrical equipment and must be earthed.
	The Noby-220iR2 incorporates fault monitoring of all circuits as required by the EN54 standard. It is important that fault indications are investigated at the earliest by a qualified engineer. Failure to do so may result in loss of life.

Specification

PSU & Battery	Value	Unit	Comment
Supply Voltage	230	VAC	+10% -6% 50Hz/60Hz
Max. Input Current	60	mA	
Battery	12	V	SLA 12V; 1.2Ah or 1.3Ah
PSU Output Voltage	13.68	V	+/- 150mV (@ I _{max.a})
PSU Absolute Max Current	200	mA	
Fuses: F1,F2 Sndr 1,2	500	mA	F500mA - quick blow
F3 Battery +vve	1.0		T1.0A - slow blow
I _{min}	8	mA	
I _{max.a}	25	mA	
I _{max.b}	-		not specified
R _{max} – Max.Battery Circuit Resistance	2.5	ohms	detection delay 60s<t<120s
Max Battery Current Draw	180	mA	with 230VAC disconnected
Standby Battery Current	10	mA	with 230VAC fault condition
Standby Battery Time	>88	hrs	see note below**
Battery Low Voltage Detection	11.0	V	detection delay 60s<t<120s
Battery Final Voltage – Auto Disconnect	10.5	V	detection delay 60s<t<120s
PSU Charger Fault Detection	Yes		detection delay 60s<t<120s
230VAC Mains Loss Detection	Yes		off delay=90s; on delay=10s

Detection Circuits	Value	Unit	Comment
No. of circuits (zones)	2		
Max detector current /circuit	1mA		e.g. 10 detectors at 100uA /circuit
End-Of-Line Capacitor EOLC	10.0	uF	non-polarised
Head Removal Monitoring	Yes		requires schottky diode bases
O/C Fault Detection	Yes		
Max Loop Resistance	400	ohms	
S/C Fault Detection	<120	ohms	
Fire Alarm Detection	120-1500	ohms	

Sounder Circuits	Value	Unit	Comment
Max. Combined Ext. Sounder Current	150	mA	@ 12.0V sounder spec. rating
End-Of-Line Resistors (EOLR)	10	Kohms	
Open Circuit Detection	>20	Kohms	
Short Circuit Detection	<5	Kohms	
Fire Alarm Relay	1.0	A	SPDT 1A/30V voltage free
Internal Panel Sounder	>85	dB	measured at 3.3m, open field
Internal Panel Fault Tone	>65	dB	

** 1.2Ah battery derated to 0.8C ≡ 88hrs standby followed by 0.5hrs in alarm with 150mA sounder o/p load.

Specification (continued)

interlink Data Bus	Value	Unit	Comment
Bus Capacity	8	Panels	
Max Cable Length	250	m	<i>standard 2 core alarm cable</i>
Max Cable Capacitance	100	nF	<i>cable length (m) X capacitance/m</i>
Max Cable Resistance	100	ohms	<i>50ohms each leg</i>

Fault Output	Value	Unit	Comment
Output Voltage Swing	12	V	<i>o/c pnp transistor - normally high</i>
Series Output Resistance	220	ohms	

Fault Input	Value	Unit	Comment
Input Voltage Range (max.)	0-30	V	
Input Resistance	100	Kohms	
Voltage Threshold	7	V	

LED Strobe/Lamp Output	Value	Unit	Comment
Output Voltage Swing	12	V	<i>open-collector pnp transistor</i>
Series Output Resistance	220	ohms	

Physical	Value	Unit	Comment
Cabinet Dimensions W x H x D	168x150x55	mm	
Net Weight	1070	g	<i>excl. battery</i>
Gross Weight	1150	g	<i>incl. carton</i>
Environmental Class EN60721-3-3:1995	3k5		<i>-5°C to +40°C; 95%RH</i>
IP Rating	IP30		<i>not protected from liquids</i>



1293

Noby UK Ltd, Unit 1F Mill Fold, Elland Road, Ripponden, Halifax, West Yorkshire, HX6 4DJ, UK.

13

1293-CPR-0385

EN 54-2 :1997 +AC :1999 +A1:2006

Control And Indicating Equipment

EN 54-4 :1997 +AC :1999 +A1:2002 +A2:2006

Power Supply Equipment

Optional Functions:

Total loss of power supply

Test condition

Output to fire alarm devices

Output to fault warning routing equipment


Noby-220iR2 User Operation

- The most commonly used functions are accessed by a simple one-touch key operation, whilst other more safety critical functions are accessed via a longer key sequence.
- The acceptance of each command is confirmed with an audible double click.
- When entering the User Access Code, the green Power LED will flash rapidly for 5 seconds signifying that the panel is ready to accept the Command Key.

<i>One-Touch Key</i>	<i>Momentary Press</i>	<i>Press & Hold for 5 secs</i>
	Silence Panel	Re-sound / Evacuate / Sounder Test <i>activates sounders & relay</i>
	LED Lamp: On / Off <i>10min timer if 230VAC OK</i> <i>60min timer if 230VAC absent</i>	LED Lamp permanently on <i>i.e. not self-timed</i>
	no action	Disable Zone-1 <i>self-timed 60mins</i> <i>disabled when Z1 yellow LEDs = on</i>
	no action	Disable Zone-2 <i>self-timed 60mins</i> <i>disabled when Z2 yellow LEDs = on</i>

<i>User Access Code</i>	<i>Command Key</i>	<i>Action</i>
  		Silence Main Sounders or, if already silenced ... Re-sound / Evacuate / Sounder Test <i>activates sounders & relay</i>
  		Panel Reset
  		Permanently Disable or Re-enable Zone-1 (Toggle on/off) <i>disabled when Z1 yellow LEDs = on</i>
  		Permanently Disable or Re-enable Zone-2 (Toggle on/off) <i>disabled when Z2 yellow LEDs = on</i>

Noby-220iR2 User Mode LED Display Indications



Note: Most LED indications remain latched until the Noby-220iR2 is Reset.

/continued

System LEDs - Interpretation

LED Label	Description	Status	Interpretation
	Power (green)	a) steady on b) off c) 1 blink / 4s d) rapid flash	230VAC Mains OK 230VAC Mains Loss 230VAC Mains Restored (memory) Code entered - awaiting a command key
	Common Fire (red)	a) steady on b) pulsing	Local fire on Zone-1 or Zone-2 Fire alarm signalled from a remote panel (the pulse count indicates the address no)
	Common Fault (yellow)	a) steady on b) 1 flash / 4s c) 2 flash / 4s	All local panel zone & sounder circuit faults, Fault I/P, remote panel and interlink bus faults. Accompanied by one or more secondary fault LEDs which identify the specific fault condition. 230VAC Mains Loss Battery Low Voltage (pending Final Voltage)

LED Label	Description	Status	Interpretation
PSU	PSU Fault (yellow)	a) 1 flash / 4s b) 2 flash / 4s c) 3 flash / 4s d) 4 flash / 4s	230VAC Mains Loss (real time status) PSU Low Volts (latched memory) PSU Charger Fault Battery O/C, Fuse F3 or Battery Ri-max fault
CPU	CPU Fault (yellow)	a) steady on b) 1 flash / 4s c) 2 flash / 4s d) 3 flash / 4s	CPU Fault (loss of comms to display PCB) CPU Watchdog occurred (restarted OK) Programme Memory Checksum Error EEPROM Data Memory Checksum Error
	Disablement (yellow)	steady on	All or part of the system is disabled
	Test (yellow)	steady on	Test Mode



Latched fault conditions are cleared by performing a Panel Reset. A persistent reoccurring fault condition could indicate a pending loss of functionality, which should be investigated by a competent person at the earliest. If in any doubt contact the installation company.

Interlink No.	House No.	Contact Name	Telephone No.
1			
2			
3			
4			
5			
6			
7			
8			

Installation Company	Contact Name	Telephone No.